

MICROTEC S.r.l.

Sede Legale Via Avvis 3/A – 21032 CARAVATE (VA) ITALY
P.IVA 02356120127 – C.F. 02356120127
Tel. +39 0332 601731 – Fax +39 0332 771777
Capitale Sociale € 10.200 i.v Reg. Imprese di Varese n. 02356120127
REA n. 251455

www.microtec.cc

**MICROTEC®**

Map description – Streetfighter 1098

Configuration file - ECD

Map configuration file name (*.ecd)	SF_1098_stdCfg
For use with	M197
ECU firmware version	1.3
ECU hardware build version	1.00.2
Created by	Microtec S.r.l.

Mapping file - EMD

Map file name (*.emd)	SF_1098_baseMap
For use with	M197
ECU firmware version	1.3
ECU hardware build version	1.00.2
Created by	Microtec S.r.l.
Spark map	Standard DP
Fuel map	Standard DP
RPM limit – spark cut	10100
RPM limit – fuel cut	10000
Tyre circumference	2.040m
Wheel triggers	4

Notes:

- Developed for use with standard exhaust + slip ons
- Standard exhaust – Exhaust valve may remain in place but will stay permanently open.